



(trouble shooting)

- PW3198
- 가 , “ ”, “ ”, “ ”, “EN50160”
- “ ”, “ ”, “ ” 가
- 10 : (flicker), (Harmonics)
- : (transient over), (swell), (dip), DC (ch4), DC (ch4) ( )  
0, 3, 5, 7, 9, 11, 0
- 1,000 ( ON 55,000 ) SD 가



PW3198



PW3198  
PW3198-90

(PC 9624-50 )

9694(AC 5A), 9660(AC 100A), 9661(AC 500A), 9669(AC 1000A),  
CT9667(AC 500A/5000A), 9657-10(AC 10A), 9675(AC 10A),  
9695-02(AC 50A), 9695-03(AC 100A)